

SOCE037-40CM Installation instructions


Please be sure to use a manual screwdriver and refrain from using an electric drill.


Eccentric rod + eccentric wheel Srews Screws Screws Screws State S





Eccentric installation principle:

























Door panel adjustment


Door gap is too big





As shown in the picture, the screw that the screwdriver points to is used to adjust the door panel to move left and right, and turning it clockwise is to adjust the door panel to move toward the center.

The gap between the door panel and the side panel is too large





As shown in the figure, loosen the screw that the screwdriver points to, push the door panel in or pull it out, and then tighten it to solve the above problem.

Uneven door panel







As shown in the figure, loosen the screw that the screwdriver points to, push the lower door panel and hinge upward, and then tighten the screw. Push the upper door panel and hinge downward, and then tighten the screw.